

1296-M015-0

ATLASWB80

INSTRUCTION MANUAL

GB

TRANSLATION FROM THE
ORIGINAL INSTRUCTIONS

For spare parts drawings refer to the section “LIST OF COMPONENTS” enclosed to this manual.

- For any further information please contact your local dealer or call:

Technical services: **SPACE s.r.l. a s.u.** - Via Sangano, 48 - 10090 Trana - Torino Italy
Phone (+39) 011 93440300 - Fax (+39) 011 9338864 - e-mail: spacesrl@tin.it

1296-M015-0 - Rev. n. 0 (05/2016)

SUMMARY

SYMBOLS USED IN THE MANUAL AND ON THE MACHINE _____ 5

1.0 GENERAL INTRODUCTION _____ 7

1.1 Introduction _____ 7

2.0 INTENDED USE _____ 7

2.1 Staff training _____ 7

3.0 SAFETY DEVICES _____ 8

3.1 Residual risks _____ 8

4.0 GENERAL SAFETY RULES _____ 8

5.0 PACKING AND MOBILIZATION FOR TRANSPORT _____ 9

6.0 UNPACKING _____ 10

7.0 MOBILIZATION _____ 10

8.0 WORKING ENVIRONMENT CONDITIONS _____ 10

8.1 Working area _____ 11

8.2 Lighting _____ 11

9.0 MACHINE ASSEMBLY _____ 11

9.1 Anchoring system _____ 11

9.2 Fixtures contained in the packing _____ 12

9.3 Assembly procedures _____ 12

9.3.1 Fitting the mandrel on the flange _____ 12

9.3.2 Fitting the protection guard _____ 13

9.3.3 Fitting of external data gauge _____ 13

9.3.4 Fitting of professional external data gauge (optional) _____ 14

9.3.5 Monitor fitting _____ 15

10.0 ELECTRICAL CONNECTION _____ 16

10.1 Electrical checks _____ 17

11.0 FITTING THE WHEEL ON THE MANDREL _____ 17

11.1 Wheel assembly _____ 17

12.0 CONTROL PANEL _____ 19

13.0 WHEEL BALANCING _____ 19

13.1 Switching the machine on and off _____ 19

13.2 Balancing programs setting _____ 20

13.2.1 Programs rapid setting and measurements through distance- diameter caliper arm _____ 20

13.2.2 Programs setting through "Measurement being acquired" screen page _____ 23

13.3 Indicative display of points where to detect measures/to fit weight _____ 24

13.3.1 Weights positioning _____ 24

13.4 Displaying the active/modifiable field _____ 24

13.5 Wheel balancing screen page description _____ 25

13.5.1 Balancing mode _____ 26

13.6 Use of machines with disabled automatic gauge _____ 28

13.6.1 Manual setting of wheel dimensions _____ 28

13.7 Standard balancing programs _____ 28

13.7.1 Static _____ 28

13.7.2 Static-1 _____ 29

13.7.3 Static-2 _____ 29

13.7.4 Dynamic _____ 29

13.7.5 ALU-S _____ 29

13.7.6 ALU-S1 _____ 30

13.7.7 ALU-S2 _____ 30

13.7.8 ALU-1 _____ 30

13.7.9 ALU-2 _____ 30

13.7.10 ALU-3 _____ 31

13.7.11 ALU-4 _____ 31

13.8 Optional balancing programs _____ 31

13.8.1 ECO-WEIGHT mode _____ 31

13.8.2 SPLIT mode _____ 33

13.8.3 Weights hidden behind spokes mode _____ 35

13.8.4 Matching mode _____ 36

13.9 Special balancing programs _____ 39

13.9.1 Pax _____ 39

13.10 Recalculation function _____ 39

13.11 Motorbike mode wheel balancing _____ 40

14.0 USER MENU (OPTIONS AND CALIBRATION) _____ 41

14.1 Options menu _____ 41

14.1.1 Lower weight limit _____ 43

14.1.2 Setting adhesive weight dimen- sions and static threshold per- centage _____ 43

14.1.3 User management _____ 44

14.2 Machine calibration _____ 45

14.2.1 Mandrel "Ø" calibration _____ 45

14.2.2 Weight measurement sensors calibration _____ 45


14.2.3 Gauge calibration _____ 46

15.0 ERROR SIGNALS _____ 50

16.0 ROUTINE MAINTENANCE	51
17.0 TECHNICAL DATA	52
17.1 Dimensions	53
18.0 STORING	54
19.0 SCRAPPING	54

20.0 REGISTRATION PLATE DATA	54
21.0 FUNCTIONAL DIAGRAMS	54
<i>Table A - Electrical and pneumatic connection diagram</i>	55
22.0 LIST OF COMPONENTS	

Fig. 1 - ATLASWB80












KEY

- 1 - Weight holding bridge
- 2 - Push-button panel with 7 keys
- 3 - Distance-diameter caliper
- 4 - Threaded mandrel
- 5 - Protection guard
- 6 - Pedal brake
- 7 - Main switch
- 8 - External data gauge
- 9 - Fixed laser unit + led light
- 10 - Monitor
- 11 - Pusher ring
- 12 - Rapid ring nut
- 13 - Lateral guard
- 14 - Cones
- 15 - Grippers for weight fitting
- 16 - Professional external data gauge (optional)


SYMBOLS USED IN THE MANUAL AND ON THE MACHINE

Symbols	Description
	Read instruction manual.
	FORBIDDEN!
 2167000	Wear work gloves.
	Wear work shoes.
 2167000	Wear safety goggles.
	Wear safety earcaps.
 99990758	Shock hazard.
	Caution: hanging loads.
	Warning. Be particularly careful (possible material damages).

Symbols	Description
	Mandatory. Operations or jobs to be performed compulsorily.
	Danger! Be particularly careful.
	Move with fork lift truck or pallet truck.
	Lift from above.
 1541000	General danger.
	Technical assistance necessary. Do not perform any intervention.
	Note. Indication and/or useful information.
 999912940	Attention: never lift the machine by means of the mandrel.
 99990114	Arrow plate.

ATLASWB80

INFORMATION PLATE LOCATION TABLE



Code numbers of plates

99990114	<i>Arrow plate</i>
99990758	<i>Electricity danger plate</i>
999910050	<i>Protection device use plate</i>
999914160	<i>Voltage 230V 50/60 Hz 1 Ph plate</i>
999912940	<i>Lifting plate</i>
999916311	<i>Rubbish skip label</i>
999920540	<i>Laser point danger plate (only for S3140RS - S3140RSP)</i>



IF ONE OR MORE PLATES DISAPPEAR FROM THE MACHINE OR BECOMES DIFFICULT TO READ, REPLACE IT AND QUOTE ITS/THEIR CODE NUMBER/S WHEN REORDERING.



SOME OF THE PICTURES AND/OR DISPLAY SCREEN PAGES PRESENT IN THIS MANUAL HAVE BEEN OBTAINED FROM PICTURES OF PROTOTYPES, THEREFORE THE STANDARD PRODUCTION MACHINES AND ACCESSORIES CAN BE DIFFERENT IN SOME COMPONENTS/DISPLAY SCREEN PAGES.

1.0 GENERAL INTRODUCTION

This manual is an integral part of the product and must be retained for the whole operating life of the machine.

Carefully study the warnings and instructions contained in this manual. It contains important instructions regarding **FUNCTIONING, SAFE USE and MAINTENANCE.**



KEEP THE MANUAL IN A KNOWN, EASILY ACCESSIBLE PLACE FOR ALL ACCESSORY OPERATORS TO CONSULT IT WHENEVER IN DOUBT.



THE MANUFACTURER DISCLAIMS ALL RESPONSIBILITY FOR ANY DAMAGE OCCURRED WHEN THE INDICATIONS GIVEN IN THIS MANUAL ARE NOT RESPECTED: AS A MATTER OF FACT, THE NON-COMPLIANCE WITH SUCH INDICATIONS MIGHT LEAD TO EVEN SERIOUS DANGERS.

1.1 Introduction

Thank you for preferring this wheel balancer. We feel sure you will not regret your decision.

This machine has been designed for use in professional workshops and stands out for its reliability and easy, safe and rapid operation. With just a small degree of maintenance and care, this wheel balancer will give you many years of trouble-free service and lots of satisfaction.

2.0 INTENDED USE

The model **ATLASWB80** machine, is a wheels balancing machine for car and light transport, projected to be used exclusively to cancel out, or at least reduce to acceptable limits the vibrations of the wheels, by fitting counterweights of suitable size and in specific positions to the same wheels that are not correctly balanced.



DANGER: EMPLOYING THESE MACHINES OUTSIDE THE USE DESTINATION THEY HAVE BEEN DESIGNED FOR (AS INDICATED IN THIS MANUAL) IS INAPPROPRIATE AND DANGEROUS.



THE MANUFACTURER CANNOT BE HELD RESPONSIBLE FOR ANY DAMAGE CAUSED BY IMPROPER, ERRONEOUS, OR UNACCEPTABLE USE.



AN INTENSIVE USE OF THE EQUIPMENT IN INDUSTRIAL ENVIRONMENT IS NOT RECOMMENDED.

2.1 Staff training

The machine may be operated only by suitably trained and authorized personnel.

Given the complexity of the operations necessary to manage the machine and to carry out the operations safely and efficiently, the personnel must be trained in such a way that they learn all the information necessary to operate the machine as intended by the manufacturer.



A CAREFUL READING OF THIS INSTRUCTION MANUAL FOR USE AND MAINTENANCE AND A SHORT PERIOD OF TRAINING WITH SKILLED PERSONNEL CAN BE AN ENOUGH PREVENTIVE PREPARATION.

3.0 SAFETY DEVICES



PERIODICALLY, AT LEAST MONTHLY, CHECK THE INTEGRITY AND THE FUNCTIONALITY OF THE SAFETY AND PROTECTION DEVICES ON THE MACHINE.


- **Master switch positioned on the rear of the machine**

Its function is to disconnect machine electric supply.

- **Protection guard**

Its function is to protect the operator from possible projections of materials on the wheel during its spin. Wheel spinning is normally prevented if the wheel protection guard is raised (open). When the protection guard is open, this interrupts the circuit that triggers the motor and automatic start is prevented, including in the case of an error.



Press  stop key to stop wheel rotation in emergency conditions.

3.1 *Residual risks*

The machine was subjected to a complete analysis of risks according to reference standard EN ISO 12100. Risks are as reduced as possible in relation with technology and product functionality.

Possible residual risks have been emphasized through pictorial representations and warnings which placing is indicated in "PLATE POSITIONING TABLE" at page 6.

4.0 GENERAL SAFETY RULES



- Any tampering with or modification to the machine not previously authorized by the manufacturer exempts the latter from all responsibility for damage caused by or derived from said actions.
- Removing of or tampering with the safety devices or with the warning signals placed on the machine leads to serious dangers and represents a transgression of European safety rules.
- Use of the machine is only permitted in places free from **explosion** or **fire** hazard and in **dry places under cover**.
- Original spare parts and accessories should be used.



THE MANUFACTURER DENIES ANY RESPONSIBILITY IN CASE OF DAMAGES CAUSED BY UNAUTHORIZED MODIFICATIONS OR BY THE USE OF NON ORIGINAL COMPONENTS OR EQUIPMENT.

- Installation must be conducted only by qualified personnel exactly according to the instructions that are given below.
- Ensure that there are no dangerous situations during the machine operating manoeuvres. Immediately stop the machine if it miss-functions and contact the assistance service of an authorized dealer.
- In emergency situations and before carrying out any maintenance or repairs, disconnect all supplies to the machine by using the main switch, placed on the machine itself, and unplugging the power supply.
- The machine electrical supply system must be equipped with an appropriate earthing, to which the yellow-green machine protection wire must be connected.
- Ensure that the work area around the machine is free of potentially dangerous objects and that there is no oil since this could damage the tyre. Oil on the floor is also a potential danger for the operator.
- UNDER NO CIRCUMSTANCES must the machine be used to spin anything but vehicle wheels. Bad locking can cause rotating parts to come loose, with potential damage to the machine and anything in the vicinity and injury to the operator.



OPERATORS MUST WEAR SUITABLE WORK CLOTHES, PROTECTIVE GLASSES AND GLOVES, AGAINST THE DANGER FROM THE SPRAYING OF DANGEROUS DUST, AND POSSIBLY LOWER BACK SUPPORTS FOR THE LIFTING OF HEAVY PARTS. DANGLING OBJECTS LIKE BRACELETS MUST NOT BE WORN, AND LONG HAIR MUST BE TIED UP. FOOTWEAR SHOULD BE ADEQUATE FOR THE TYPE OF OPERATIONS TO BE CARRIED OUT.

- The machine handles and operating grips must be kept clean and free from oil.
- The workshop must be kept clean and dry. Make sure that the working premises are properly lit. The machine can be operated by a single operator. Unauthorized personnel must remain outside the working area, as shown in **Fig. 3**. Avoid any hazardous situations. Do not use air-operated or electrical equipment when the shop is damp or the floor slippery and do not expose such tools to atmospheric agents.
- When operating and servicing this machine, carefully follow all applicable safety and accident-prevention precautions. The machine must not be operated by professionally unskilled persons.

5.0 PACKING AND MOBILIZATION FOR TRANSPORT




HAVE THE MACHINE HANDLED BY SKILLED PERSONNEL ONLY.

THE LIFTING EQUIPMENT MUST WITHSTAND A MINIMUM RATED LOAD EQUAL TO THE WEIGHT OF THE PACKED MACHINE (SEE PARAGRAPH "TECHNICAL SPECIFICATIONS").

The machine is packed completely assembled. The machine is inside a carton box which size is mm 1040x950x1090.

Movement must be by pallet-lift or fork-lift trolley. The fork lifting points are indicated on the packing.

Fig. 2



6.0 UNPACKING



DURING UNPACKING, ALWAYS WEAR GLOVES TO PREVENT ANY INJURY CAUSED BY CONTACT WITH PACKAGING MATERIAL (NAILS, ETC.).



The cardboard box is supported with plastic strapping. Cut the strapping with suitable scissors. Use a small knife to cut along the lateral axis of the box and open it like a fan.

It is also possible to unnailed the cardboard box from the pallet it is fixed to. After removing the packing, and in the case of the machine packed fully assembled, check that the machine is complete and that there is no visible damage.

If in doubt **do not use the machine** and refer to professionally qualified personnel (to the seller).

The packing (plastic bags, expanded polystyrene, nails, screws, timber, etc.) should not be left within reach of children since it is potentially dangerous. These materials should be deposited in the relevant collection points if they are pollutants or non biodegradable.



THE BOX CONTAINING THE FIXTURES IS CONTAINED IN THE WRAPPING. DO NOT THROW IT AWAY WITH THE PACKING.

7.0 MOBILIZATION



THE LIFTING EQUIPMENT MUST WITHSTAND A MINIMUM RATED LOAD EQUAL TO THE WEIGHT OF THE MACHINE (SEE PARAGRAPH TECHNICAL SPECIFICATIONS). DO NOT ALLOW THE LIFTED MACHINE TO SWING.



NEVER LIFT THE MACHINE BY MEANS OF THE MANDREL.

If the machine has to be moved from its normal work post, the movement must be conducted following the instructions listed below.

- Protect the exposed corners with suitable material (Pluribol/cardboard).
- Do not use metallic cables for lifting.
- Make sure that the electricity supply is not connected.
- Place again the machine onto the original pallet with whom it was delivered.
- Use transpallet or fork-lift for handling.

8.0 WORKING ENVIRONMENT CONDITIONS


The machine must be operated under proper conditions as follows:

- temperature: 0° + 45° C
- relative humidity 30 - 90% (dew-free)

atmospheric pressure: 860 - 1060 hPa (mbar).

The use of the machine in ambient conditions other than those specified above is only allowed after prior agreement with and approval of the manufacturer.

8.1 Working area



The location of the machine requires a usable space as indicated in **Fig. 3**. The positioning of the machine must be according to the distances shown. From the control position the operator is able to observe all the machine and surrounding area. He must prevent unauthorized personnel or objects that could be dangerous from entering the area.

The machine must be fixed on a flat floor surface, preferably of cement or tiled. Avoid yielding or irregular surfaces.

The base floor must be able to support the loads transmitted during operation.


This surface must have a capacity load of at least 500 kg/m².

The depth of the solid floor must be sufficient to guarantee that the anchoring bolts hold.

8.2 Lighting

The machine does not require its own lighting for normal working operations. However, it must be used in an adequately lit environment.

In case of poor lighting use lamps having total power 800/1200 Watt.





9.0 MACHINE ASSEMBLY

Remove the various components from the packing, check that they are complete and that there are no anomalies, then comply with the following instructions for components assembly, using the attached series of illustrations.

9.1 Anchoring system

The packed machine is fixed to the support pallet through the holes prearranged on the frame. Such holes can be used also to fix the machine to the ground, through floor anchor small blocks (excluded from supply). Before carrying out the definitive fixing, check that all the anchor points are laid down flat and correctly in contact with the fixing surface itself. If not so, insert shimming profiles between the machine and the fixing lower surface, as indicated in **Fig. 4**.




- Execute 4 holes with 10 mm diameter on the floor by the holes on the bottom floor;
- insert the small blocks (excluded from supply) into the holes;
- fix the machine to the ground with 4 M8x80 mm screws (excluded from supply) (**Fig. 4 ref. 1**) (or with 4 8x80 mm stud bolts (excluded from supply)). Tighten the screws with an approximate tightening torque of 70 Nm.

9.2 Fixtures contained in the packing

The packing case contains also the fixtures box.
Check that all the parts listed below are there (see Fig. 5).

Code	Description	N.
GAR101	Rapid ring nut + pusher ring	1
GAR111	Cones + protection cup	1
129571492	Gauge	1
1300A004	Weight pliers	1
999072	Carriages counterweight	1
129590750	External data gauge	1

Fig. 5




THE GRIP-RING (FIG. 5 REF. A) MUST BE MOUNTED WITH THE TEETH OR DISCHARGE SIDE TOWARDS THE RING-NUT (SEE FIG. 5).

9.3 Assembly procedures


9.3.1 Fitting the mandrel on the flange

Screw the mandrel with an Allen wrench (Fig. 6 ref. 1) on the flange (Fig. 6 ref. 2).




9.3.2 Fitting the protection guard


1. Screw the 3 screws (**Fig. 7 ref. 1**) and the washers (**Fig. 7 ref. 2**) to the guard support (**Fig. 7 ref. 3**) in the special inserts positioned in the rear side of the frame, by means of an Allen wrench.
2. Fit the spring (**Fig. 7 ref. 4**) between the base of the support and the anchor pin.
3. Connect the 2 wires (**Fig. 7 ref. 5**) from inside the frame to the normally open (NO) microswitch contacts (**Fig. 7 ref. 6**).

Fig. 7**9.3.3 Fitting of external data gauge**


1. Unscrew the fastening screws of the equalizer's support (**Fig. 8 ref. 1**), being very careful about holding the same support.
2. Screw the 4 screws (**Fig. 8 ref. 2**) to the gauge bracket (**Fig. 8 ref. 3**) and in the special inserts placed on the rear side of the frame. Lock the gauge arm (**Fig. 8 ref. 4**) by screwing the 2 screws provided (**Fig. 8 ref. 5**). Lock these screws with the nuts (**Fig. 8 ref. 6**) and the washers (**Fig. 8 ref. 7**) so that the mandrel and the gauge arm are levelled out (see **Fig. 8**).

**Fig. 8**

3. Also make sure the gauge tip (**Fig. 9 ref. 1**) is positioned at the centre of the mandrel.


**Fig. 9**

4. Connect connector (**Fig. 10 ref. 1**) of the cable coming from inside the machine to connector (**Fig. 10 ref. 2**) of the cable coming from the gauge arm. Fit the section of the cable with the connectors inside the arm (**Fig. 10 ref. 3**).
5. Fasten the cable with clamps.
6. Enable the external data gauge and carry out the device's calibration.




9.3.4 Fitting of professional external data gauge (optional)

1. Unscrew the fastening screws of the equalizer's support (**Fig. 11 ref. 1**), being very careful about holding the same support.
2. Screw the 4 screws (**Fig. 11 ref. 2**) to the gauge bracket (**Fig. 11 ref. 3**) and in the special inserts placed on the rear side of the frame. Lock the gauge arm (**Fig. 11 ref. 4**) by screwing the 2 screws provided (**Fig. 11 ref. 5**). Lock these screws with the nuts (**Fig. 11 ref. 6**), so that the mandrel and the gauge arm are levelled out (see **Fig. 12**).



3. Also make sure the gauge tip (**Fig. 12 ref. 1**) is positioned at the centre of the mandrel.



4. Connect connector (**Fig. 13 ref. 1**) of the cable coming from inside the machine to connector (**Fig. 13 ref. 2**) of the cable coming from the gauge arm. Fit the section of the cable with the connectors inside the arm (**Fig. 13 ref. 3**).
5. Fasten the cable with clamps.
6. Enable the external data gauge and carry out the device's calibration.




Fig. 13

9.3.5 Monitor fitting

1. Mount the monitor support (**Fig. 14 ref. 1**) to the screws (**Fig. 14 ref. 2**) of the frame, laying the plate (**Fig. 14 ref. 3**) paying attention to the monitor and keyboard cables (**Fig. 14 ref. 4**) inside it. Then, tighten the nuts (**Fig. 14 ref. 5**). At the end fit the guard (**Fig. 14 ref. 6**) using the screws (**Fig. 14 ref. 7**).





Fig. 14


2. Connect the plugs on the power supply sockets and monitor signal. Connect the wiring of the keyboard.
3. Fix the monitor (**Fig. 15 ref. 1**) to the support (**Fig. 15 ref. 2**) with the screws (**Fig. 15 ref. 3**) and the washers (**Fig. 15 ref. 4**) supplied.

Fig. 15



4. Mount the guard (**Fig. 16 ref. 1**) to the support (**Fig. 16 ref. 2**) with the 6 screws (**Fig. 16 ref. 3**) and the washers (**Fig. 16 ref. 4**) supplied.

Fig. 16



10.0 ELECTRICAL CONNECTION



EVEN THE TINIEST PROCEDURE OF AN ELECTRICAL NATURE MUST BE CARRIED OUT BY PROFESSIONALLY QUALIFIED STAFF.



BEFORE CONNECTING THE MACHINE MAKE SURE THAT:

- **THE MAIN POWER RATING CORRESPONDS TO THE MACHINE RATING AS SHOWN ON THE MACHINE PLATE;**
- **ALL MAIN POWER COMPONENTS ARE IN GOOD CONDITION;**
- **THE ELECTRICAL SYSTEM IS PROPERLY GROUNDED (GROUND WIRE MUST BE THE SAME CROSS-SECTION AREA AS THE LARGEST POWER SUPPLY CABLES OR GREATER);**
- **MAKE SURE THAT THE ELECTRICAL SYSTEM FEATURES A CUTOUT WITH DIFFERENTIAL PROTECTION SET AT 30 mA.**

Connect the machine up to the mains by means of the 3-pole plug provided (230 V single-phase).

If the plug provided is not suitable for the wall socket, fit a plug that complies with local and applicable regulations. This operation must be performed by expert and professional personnel.



FIT A TYPE-APPROVED (AS REPORTED BEFORE) PLUG TO THE MACHINE CABLE (THE GROUND WIRE IS YELLOW/GREEN AND MUST NEVER BE CONNECTED TO THE PHASE LEADS). MAKE SURE THAT THE ELECTRICAL SYSTEM IS COMPATIBLE WITH THE RATED POWER ABSORPTION SPECIFIED IN THIS MANUAL AND APT TO ENSURE THAT VOLTAGE DROP UNDER FULL LOAD WILL NOT EXCEED 4% OF RATED VOLTAGE (10% UPON START-UP).



FAILURE TO OBSERVE THE ABOVE INSTRUCTIONS WILL IMMEDIATELY INVALIDATE THE WARRANTY.

10.1 Electrical checks



BEFORE STARTING UP THE WHEEL-BALANCER, BE SURE TO BECOME FAMILIAR WITH THE LOCATION AND OPERATION OF ALL CONTROLS AND CHECK THEIR PROPER OPERATION (SEE PAR. "CONTROLS").



CARRY OUT A DAILY CHECK OF MAINTAINED-TYPE CONTROLS CORRECT FUNCTIONING, BEFORE STARTING MACHINE OPERATION.

Once the plug/socket connection has been made, turn on the machine using the master switch (**Fig. 17 ref. 1**).




Fig. 17

11.0 FITTING THE WHEEL ON THE MANDREL



To achieve perfect balancing, the wheel must be carefully and properly fitted on the mandrel. Imperfect centring will inevitably cause unbalances.



MOST IMPORTANT IS THAT ORIGINAL CONES AND ACCESSORIES ARE USED MADE SPECIFICALLY FOR USE ON THE WHEEL BALANCER.

Wheel fitting using the cones provided is illustrated below. For alternative fittings, using optional accessories, refer to the special instructions provided separately.

11.1 Wheel assembly

1. Remove any type of foreign body from the wheel (**Fig. 18 ref. 3**): pre-existing weights, stones and mud, and make sure the mandrel (**Fig. 18 ref. 1**) and the rim centring area are clean before fitting the wheel on the mandrel.
2. Carefully choose the cone (**Fig. 18 ref. 2**) most suitable for the wheel to be balanced. These accessories must be selected according to the shape of the rim. Position the wheel (**Fig. 18 ref. 3**), fitting the cone (**Fig. 18 ref. 2**) on the mandrel (**Fig. 18 ref. 1**): be careful (otherwise this could seize) until this rests against the support flange (**Fig. 18 ref. 4**).
3. Fit the wheel with the inner side of the rim towards the wheel balancer and against the cone.




Fig. 18

4. Fit the protection cap (**Fig. 19 ref. 1**) in the locknut (**Fig. 19 ref. 2**) and fasten against the wheel.




Fig. 19

Some aluminium wheels, with very high centring, must be fitted with the cone outside the wheel.

5. Clean the mandrel (**Fig. 20 ref. 1**) before fitting the wheel.
6. Fit the wheel (**Fig. 20 ref. 3**) with the inside of the rim towards the wheel balancer, until the wheel is up against the support flange (**Fig. 20 ref. 2**).




Fig. 20

7. Fit the cone (**Fig. 21 ref. 3**) with the narrowest part turned towards the wheel.

8. Fit the grip-ring (**Fig. 21 ref. 1**) in the nut (**Fig. 21 ref. 2**) and fasten the cone (**Fig. 21 ref. 3**).




Fig. 21




THE GRIP-RING (FIG. 21 REF. 1) MUST BE MOUNTED WITH THE TEETH SIDE TOWARDS THE RING-NUT (FIG. 21 REF. 2).

12.0 CONTROL PANEL

The wheel balancers are equipped with a control panel equipped with a keyboard to interact/operate the controls presented in graphical form on the monitor. On the monitor are displayed all the instructions for the correct wheel balancing, for example indicating where the operator shall fit adhesive or clip weights and the balancing mode and/or option used, as well as correct wheel rotation for inner/outer weights positioning.

Fig. 22



KEY

- 1 – Monitor
- 2 – Function push button (red)
- 3 – Function push button (yellow)
- 4 – Function push button (grey)
- 5 – Function push button (blue)
- 6 – Function push button (green)
- 7 – Previous page push button
- 8 – Next page/print push button
- 9 – Push-button panel (push-button panel with 7 keys)


13.0 WHEEL BALANCING

13.1 Switching the machine on and off

Press the "ON" switch (**Fig. 17 ref. 1**), located in the rear part of the equipment.

Wait a few seconds until the complete loading of the operational program. The equipment is ready to operate when the main screen "Home" appears on the monitor.

Fig. 23




KEY

- A – Displaying operations/information area
- B – Colours for identification of the buttons to be used
- C – Function icons
- 1 – Programs and measurements acquisition buttons
- 2 – Wheel spin push-button
- 3 – Go to next page
- 4 – User management (if enabled)
(user management is not enabled on machine delivery)

At the bottom of the main screen and each screen described below, there will be coloured rectangles (**Fig. 23 ref. B**) located above the icons of identification function (**Fig. 23 ref. C**). These functions are activated by pressing the appropriate coloured button on the keypad (**Fig. 22 ref. 9**). Press the button (**Fig. 23 ref. 3**) to display a second page where you can access the "Technical assistance" menu and the "Run-out" menu (see **Fig. 24**).


Fig. 24



In order to turn off the machine, simply press the "OFF" switch (**Fig. 17 ref. 1**).




WHEN THE EQUIPMENT IS TURNED OFF LOSES ALL THE MEASUREMENTS AND THE STORED DATA (SIZE, SPINS, USERS, ETC ...). AT RESTARTING,

PRESSING THE BUTTON  (IN THE CASE HAVE NOT YET BEEN STORED ON THE NEW MEASURES AFTER THE SWITCHING ON), THE MACHINE DOES NOT PERFORM ANY OPERATION.

13.2 Balancing programs setting

The setting of the balancing programs can be performed in two ways:

- through the gauge arm (rapid setting);
- through "Measurement being acquired" screen, ap-

pearing when the  button is pressed (**Fig. 23 ref. 1**).

The setting modes are completely different even if they allow to reach the same result (but with different times).

13.2.1 Programs rapid setting and measurements through distance-diameter caliper arm

The use of the distance-diameter caliper arm allows the rapid automatic wheel balancing program and the measures entry. From page "Home":

- bring into contact the weights fitting gripper with the inner part of the rim (1 contact only) to select the program "STATIC" (see **Fig. 25**).



Fig. 25



REPEATEDLY BRINGING THE GAUGE'S ARM (FIG. 26 REF. 1) IN CONTACT WITH THE MANDREL (FIG. 26 REF. 2), THE PROGRAM WILL CYCLE FROM "STATIC" TO "STATIC 1" TO "2 STATIC" THEN RETURNING TO THE BEGINNING.




Fig. 26

- bring into contact the weights fitting gripper with the inner part of the rim (2 contact points) (see Fig. **Fig. 25**) to select "ALU-S" program.




REPEATEDLY BRINGING THE GAUGE'S ARM (FIG. 26 REF. 1) IN CONTACT WITH THE MANDREL (FIG. 26 REF. 2), THE PROGRAM WILL CYCLE FROM "ALU-S" TO "ALU-S1" TO "ALU-S2" THEN RETURNING TO THE BEGINNING.




WHENEVER THE DISTANCE-DIAMETER CALIPER AND/OR THE EXTERNAL DATA GAUGE (GAR266 OR GAR264, SEE FIG. 27) (IF ANY) IS KEPT IN POSITION FOR A FEW SECONDS AGAINST THE RIM (UNTIL THE MACHINE MAKES AN APPROPRIATE SOUND NOTIFICATION) , THE POSITION IS STORED AND THE VALUES MEASURED IN THE PRE-ARRANGED FIELDS IN THE SELECTED WHEEL BALANCING PROGRAM ARE LOADED.

Fig. 27



GAR266



GAR264

- After entering all the required measures, you can spin



the wheel by pressing the button and closing the protective guard.

- **Measuring procedure of electronic RUN-OUT with the distance-diameter caliper arm.**

The electronic RUN-OUT measuring device is useful to check if the rim has some imperfections.

To access the screen to choose the rim control mode, proceed as follows:



- from the "Home" page, press the button




(Fig. 28 re. 1) and then the button (see Fig. 29 ref. 1).


Fig. 28



Fig. 29




- On the monitor you will see the screen below where there are buttons to select the type of flaw detection.





Tyre fault detection (lateral inner side).

From the screen page in **Fig. 30** press the button (**Fig. 30 ref. 3**). The screen page below is displayed.



Place the distance-diameter caliper grippers (**Fig. 31 ref. 1**) on the inner side of the rim, as shown in **Fig. 31**.

Press the green button on the monitor (**Fig. 30 ref. 5**) to start the rim analysis procedure. The circle starts to spin at low speed (30 rpm) and at the end of the measurement the eccentricity graph appears, as shown in the **Fig. 32**.



The red graph (**Fig. 32 ref. 2**) represents exactly the geometric shape of the rim. The more the circle is round and linear, the more the graph is flat, unlike the more the circle has deficiencies, the more the graph is large.

You can follow the eccentricity in the graph by manually turning the rim, the green-coloured-slider (**Fig. 32 ref. 3**), indicates the position of the rim in "12 o'clock" position.

13.2.2 Programs setting through "Measurement being acquired" screen page



From the "Home" page, press the (Fig. 23 ref. 1) button to display the "Measurement being acquired" screen below:



PRESS THE BUTTON

(Fig. 23 ref. 1) TO DISABLE AUTOMATIC FUNCTION OF THE DISTANCE-DIAMETER CALIPER ARM WHEEL BALANCING SELECTION, DESCRIBED IN PAR. 13.2.1. TO BE ABLE TO REUSE THE AUTOMATIC FUNCTION TO SELECT THE WHEEL BALANCING PROGRAM WITH GAUGE ARM, IT IS NECESSARY TO RETURN TO "HOME" PAGE, BY PRESSING THE

BUTTON

The selection of the wheel balancing program is possible in 2 ways:

- with highlighted program (blue colour) by pressing the or until you see the desired program. With this mode only the 11 standard programs can be selected (DYN, ALU-S, ALU-S1, ALU-S2, STAT, STAT-1, STAT-2, ALU-1, ALU-2, ALU-3, ALU-4). After selecting the wished program, take the measurements.

IF THE PROGRAM NAME IS NOT HIGHLIGHTED (BLUE), PRESS

THE BUTTON **REPEATEDLY UNTIL THE ABOVE CONDITION IS REACHED.**

- Press the button to display the following programs selection screen page:



Use the arrows and/or to select the wished mode (blue). In this mode you can select the 11 standard programs (listed above) and special programs (PAX360, PAX420, PAX460, PAX700).

After selecting the wished program press to confirm the choice.

AFTER YOU HAVE SELECTED THE DESIRED PROGRAM, USE THE DISTANCE-DIAMETER CALIPER AND/OR THE EXTERNAL DATA GAUGE (GAR266 OR GAR264) (IF ANY) TO DETECT THE MEASURES REQUIRED BY THE PROGRAM.

WHENEVER THE DISTANCE-DIAMETER CALIPER AND/OR THE EXTERNAL DATA GAUGE (GAR266 OR GAR264, SEE FIG. 27) (IF ANY) IS KEPT IN POSITION FOR A FEW SECONDS AGAINST THE RIM (UNTIL THE MACHINE MAKES AN APPROPRIATE SOUND NOTIFICATION) , THE POSITION IS STORED AND THE VALUES MEASURED IN THE PRE-ARRANGED FIELDS IN THE SELECTED WHEEL BALANCING PROGRAM ARE LOADED.


- After entering all the required measures, you can spin the wheel by pressing the button and closing the protective guard.

13.3 Indicative display of points where to detect measures/to fit weight



IT IS VERY IMPORTANT TO REMEMBER THE POINTS SELECTED FOR MEASUREMENT INSIDE THE RIM SINCE DURING THE WEIGHTS FITTING WITH FIXED LASER YOU WILL NOT HAVE ANY OTHER REFERENCE EXCEPT FOR THE CROSS LINE ON THE RIM, GENERATED BY THE LASER ITSELF. THE POSITIONING IN DEPTH WILL BE AT THE DISCRETION OF THE OPERATOR.

Depending on the type of program selected, the machine shows on the monitor the guideline points where to take measures and, consequently, where you must apply weights (**Fig. 33 ref. 4-5**).



KEY

- 1 – 1st weight fitting point distance
- 2 – Rim diameter
- 3 – Balancing mode
- 4A-B – Point at which to take the measure/adhesive weight fitting
- 4C – Point where fitting the adhesive weight
- 5 – Point at which to take the measure/clip weight fitting
- 6 – Last unbalance detected by the machine
- 7 – Rim width



THE MORE THE POINTS CHOSEN FOR THE PROBING ARE DISTANT FROM EACH OTHER THE MORE THE BALANCING WILL BE EFFECTIVE.

13.3.1 Weights positioning

The monitor displays when it is absolutely necessary that the weight is applied at "12 o'clock" position. Pay particular attention to the content of the weights identification icons since if the following words **H 12** are displayed, then the icon corresponding weight has to be applied at "12 o'clock" position (typical of ALU-S1, ALU-S2 programs).





IF ALL MEASURES REQUIRED BY THE PROGRAM HAVE NOT BEEN TAKEN/INSERTED, THE MACHINE DOES NOT ALLOW THE WHEEL SPIN TO DETECT THE UNBALANCE.

13.4 Displaying the active/modifiable field

During the various phases of measures detection, the active field turns blue.



Pressing the buttons  or  you can change the value and/or program inside the active field. To change the selected active field, simply press the button



until the desired field is coloured blue.



THE SELECTION OF THE ACTIVE FIELD IS DONE BY HIGHLIGHTING THE FIELDS IN A CLOCKWISE DIRECTION.

NORMALLY DURING THE DETECTION OF MEASUREMENTS, THE 1ST ACTIVE FIELD WILL BE THE ONE FOR THE SELECTION OF THE PROGRAM.



THERE IS A CASE, HOWEVER, IN WHICH THE 1ST ACTIVE FIELD WILL BE THE RIM WIDTH.




THIS CASE WILL OCCUR ONLY IF FROM "HOME" PAGE IS DETECTED ONLY ONE MEASUREMENT INSIDE THE RIM. THE PROGRAM WILL AUTOMATICALLY SET TO "STATIC" BUT IT WILL MAKE IT POSSIBLE (IN CASE OF ABSENCE OF EXTERNAL DATA GAUGE) TO MANUALLY ENTER RIM WIDTH AND TO QUICKLY SWITCH TO THE PROGRAM "DYNAMIC".


13.5 Wheel balancing screen page description

After executing the spin of the wheel, the monitor displays a series of important information that helps the operator in his operations and subsequent choices.

Fig. 34




KEY

- 1 – Measures used by the program to perform the spin and detect the values in P1 - P2
- P1 – Weight to be fitted on rim outer side
- P2 – Weight to be fitted on rim inner side
- 2 – Wheel placed to fit the weight on wheel outer side (arrows both green)
- 3 – Wheel not placed to fit the weight on wheel inner side (blue/black arrows)
- 4 – Wheel balancing suggestions
- 4a – SPLIT Program (Clip weights program) or MATCHING Program
- 4b – SPOKES Program (program with adhesive weights)
- 4c – ECO-WEIGHT Program with weight value to be fitted (if the value is of blue, the machine advises not to use it)
- 4d – STATIC Program
- 5 – N° user (if selected)
- 6 – Arrows indicating the weight fitting point with distance-diameter caliper arm
- 7 – Wheel repositioning button for weights fitting
- 8 – Display the actual weight
- 9 – By pressing the button  you will see the following page where you can select one of the programs suggested by the machine.



IF THE GUARD AND REPOSITION-
ING FUNCTION ARE DISABLED,
ON FIG. 34 REF. 7 BUTTON YOU



WILL SEE THE ICON  THAT
WILL ALLOW THE WHEEL SPIN
WITHOUT RETURNING TO THE
PREVIOUS PAGE. THE POSITION-
ING OF THE WHEEL FOR THE
APPLICATION OF THE WEIGHTS
MUST BE DONE MANUALLY.

13.5.1 Balancing mode

The machine has the ability to perform the wheel bal-
ancing (weights fitting) in 3 different ways:

- using the distance-diameter caliper arm with weights fitting grippers;
- using the laser at "6 o'clock";
- weights fitting at "6 o'clock" (without the use of lasers).

• **Weights fitting with distance-diameter caliper arm.**

1. Place the adhesive weight on the arm grippers.

Fit the adhesive weight in the
pliers of the gauge rod




2. Pull out the gauge until the arrows (**Fig. 34 ref. 6**) both turn green.
3. Rotate the gauge arm until the weight touches the rim.

Fit weight on the position where
pliers touches the wheel



4. Bring the distance-diameter caliper arm into resting position.



5. Press the  button to change the weight fitting side.
6. Proceed in the same way as described in points 1-2-3.



BEFORE REMOVING THE DIAMETER-DISTANCE CALIPER, PRESS THE BRAKE PEDAL AND HOLD IT DOWN UNTIL THE WEIGHT HAS NOT BEEN APPLIED, ENSURING IN THIS WAY THAT, DURING THESE PHASES, THE WHEEL CAN NOT ROTATE.

• **Weights fitting with laser (at "6 hours").**



ON DELIVERY THE MACHINE (IF PRE-SET WITH FIXED LASER) IS SET WITH THE CORRESPONDING OPTION DESELECTED.

TO USE THIS MODE, IT IS NECESSARY THAT THE RELEVANT FUNCTION IS ENABLED



ON THE MENU "OPTIONS" DESCRIBED IN PAR. 14.1.



TO USE THIS WEIGHTS APPLICATION MODE THE OPERATOR MUST REMEMBER THE PRECISE POINT AT WHICH THE MEASUREMENT WAS TAKEN WITH THE DISTANCE-DIAMETER CALIPER ARM.

At the end of the spin, on the rim at "6 hours" is displayed a laser beam (blade) indicating the axis on which to apply the weight. The positioning of the weight (s) in depth shall be at the discretion of the operator, depending on where remembers taking the measure.



BE SURE TO APPLY THE (INTERNAL OR EXTERNAL) WEIGHT AS INDICATED BY THE 2 GREEN ARROWS (Fig. 34 ref. 2 or 3) ON THE CORRESPONDING MONITOR SCREEN.

• **Weights fitting at "6 o'clock" (without the use of lasers).**



TO USE THIS MODE, IT IS NECESSARY THAT THE RELEVANT FUNCTION IS ENABLED



ON THE MENU "OPTIONS" DESCRIBED IN PAR. 14.1.



TO USE THIS WEIGHTS APPLICATION MODE THE OPERATOR MUST REMEMBER THE PRECISE POINT AT WHICH THE MEASUREMENT WAS TAKEN WITH THE DISTANCE-DIAMETER CALIPER ARM.



USING THIS MODE, THE MACHINE ALLOWS YOU TO APPLY ANY ADHESIVE WEIGHTS THAT WOULD BE APPLIED TO "12 HOURS" TO "6 O'CLOCK". IF, AFTER YOU ENABLE THIS MODE, ON BALANCING PROGRAM APPEARED AGAIN THE **H 12 ICON (ONLY IN THIS CASE) THE ADHESIVE WEIGHT WILL BE APPLIED TO "12 HOURS".**

At the end of the spin, the wheel stops in place to apply the weight at "6 o'clock". The positioning of the weight (s) in depth shall be at the discretion of the operator, depending on where remembers taking the measure.



BE SURE TO APPLY THE WEIGHT (INTERNAL OR EXTERNAL) AS INDICATED BY THE 2 GREEN ARROWS (Fig. 34 ref. 2 or 3) ON THE CORRESPONDING MONITOR SCREEN.

13.6 Use of machines with disabled automatic gauge

The entry of diameter, width and distance measures of the machine rim must be performed manually. The reading of these measures can be made as follows:

- visual readout on caliper graduated scale (distance);
- values readout on rim (diameter and width);
- width value detection with manual caliper (width) (see **Fig. 35**).




Fig. 35

13.6.1 Manual setting of wheel dimensions

In case the operator wants to edit and/or manually enter the wheel dimensions, proceed as follows:

- from the desired measurement mode screen, press




the button until highlighting with blue the field to modify/edit;



- press the buttons until reaching the desired value;



- press button to shift to the next value.



After entering all the required measures, you can spin



the wheel by pressing the button and closing the protective guard.

NOTE: if the distance-diameter caliper is disabled, the displayed page for detected unbalance is as follows:



In this screen page, in addition to the information of the detected unbalance, there are measurements in mm where you must remove the gauge arm (**Fig. 36 ref. 1-2**) to apply the weights inside the rim.

13.7 Standard balancing programs

13.7.1 Static

The STATIC program permits balancing wheels by fitting adhesive weights on the outer and inner sides of the rim. Enter the measurements (see Par. 13.2.1 or 13.6.1) and proceed as described in Par. 13.5.

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.




The procedure has now been completed.

13.7.2 Static-1

STATIC 1 function is a procedure that offsets wheel vibrations using a single weight with clip on a single plane positioned exactly at 12 o' clock.

Enter the measurements (see Par. 13.2.1 or 13.6.1) and proceed as described in Par. 13.5 "Dynamic balancing" (only for wheel inner side).

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.



The procedure has now been completed.

13.7.3 Static-2

STATIC 2 function is a procedure that offsets wheel vibrations using a single adhesive weight on a single plane positioned exactly at 12 o' clock.

Enter the measurements (see Par. 13.2.1 or 13.6.1) and proceed as described in Par. 13.5 "Dynamic balancing" (only for wheel inner side).

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.




The procedure has now been completed.

13.7.4 Dynamic

The DYNAMIC program allows the wheels balancing by fitting two clip weights at 12 o' clock: one on the outside and one on the inside rim. It is possible to enter the measurements in two ways:

- with distance and diameter caliper and outer width feeler pin. If the feeler pin is missing, enter the measurement manually (see **Fig. 35**);
- follow the procedure in Par. 13.6.1 and proceed as described in Par. 13.5.

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.



The procedure has now been completed.

13.7.5 ALU-S

ALU-S program permits balancing wheels by two fitting adhesive weights on the outer and inner sides of the rim. Enter the measurements (see Par. 13.2.1 or 13.6.1) and proceed as described in Par. 13.5.

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.



The procedure has now been completed.

13.7.6 ALU-S1

ALU-S1 function permits balancing wheels with light alloy rims by fitting adhesive weights on the outer side and weight with clip on inner side of wheel (at 12 o' clock).

Enter the measurements (see Par. 13.2.1 or 13.6.1) and proceed as described in Par. 13.5 (the inner weight is with clip).

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.



The procedure has now been completed.

13.7.7 ALU-S2

ALU-S2 function permits balancing wheels with light alloy rims by fitting two adhesive weights: one on the outer and one on inner sides of the rim (the inner weight is at 12 o' clock).

Enter the measurements (see Par. 13.2.1 or 13.6.1) and proceed as described in Par. 13.5.

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.



The procedure has now been completed.

13.7.8 ALU-1

ALU-1 function permits balancing wheels with light alloy rims by fitting adhesive weights on the outer and inner sides of the rim at 12 o' clock.

Enter the measurements (see Par. 13.2.1 or 13.6.1) and proceed as described in Par. 13.5.

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.



The procedure has now been completed.

13.7.9 ALU-2

ALU-2 function balances wheels with light alloy rims by fitting adhesive weights on the outside and inside of the rim. The position of the outer weight is not visible but hidden inside. Enter the measurements (see Par. 13.2.1 or 13.6.1) and proceed as for dynamic unbalance.

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.




The procedure has now been completed.

13.7.10 ALU-3

ALU-3 function is a procedure that uses mixed weights to offset wheel unbalance: weight with clip on inner side of wheel, adhesive weight on outer side, not visible because inside the rim.

Enter the measurements (see Par. 13.2.1 or 13.6.1) and proceed as for dynamic unbalance.

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.




The procedure has now been completed.

13.7.11 ALU-4

ALU-4 function is a procedure that uses mixed weights to offset wheel unbalance: weight with clip on inner side of wheel, adhesive weight on outer side.

Enter the measurements (see Par. 13.2.1 or 13.6.1) and proceed as for dynamic unbalance.

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.



The procedure has now been completed.

13.8 Optional balancing programs

13.8.1 ECO-WEIGHT mode



TO USE THE ECO-WEIGHT PROCEDURE IT IS NECESSARY THAT THE DISTANCE-DIAMETER CALIPER ARM IS ENABLED IN THE "OPTIONS" MENU DESCRIBED IN PAR. 14.1.



THE ECO-WEIGHT PROCEDURE CAN ONLY BE USED WITH THE PROGRAM ALU-S.

This procedure represents a modern system for the reset of the unbalance in order to reduce weights consumption. This procedure ensures a fastest execution of the operations, thanks to a lesser number of spins and repositioning.

After making the wheel spin in ALU-S mode, the monitor shows the total of 2 adhesive weights to precisely correct STATIC and DYNAMIC unbalance.



It is possible to fit a single weight at a predetermined distance from the machine, so as to optimize the weight consumption and reduce both the DYNAMIC and any remaining STATIC unbalance as much as possible. Unlike the standard STATIC procedure, the ECO-WEIGHT procedure, though only using one weight, also considerably reduces the DYNAMIC unbalance, because the fitting distance of the weight on the rim is also calculated.


From ALU-S unbalance results page, if there is con-

siderable static unbalance, press the button



to display on the following monitor screen:



Press button  to select such procedure and bring automatically the wheel into weight fitting position.




Fig. 37

KEY

- 1 – Only weight to be fitted
- 2 – Last program and last values used for the spin
- 3 – Residual dynamic unbalance value (if the value is blue it is not to carry out ECO-WEIGHT procedure)
- 4 – Static unbalance value (if the value is blue it is not to carry out ECO-WEIGHT procedure)
- 5 – Residual dynamic unbalance value (if the value is blue it is not to carry out ECO-WEIGHT procedure)
- 6 – Arrows indicating the weight fitting point with distance-diameter caliper arm

Press the brake pedal and fit the adhesive weight inside pliers as shown in **Fig. 38**.

Fig. 38 Fit the adhesive weight in the pliers of the gauge rod



Pull out the gauge rod until the arrows (**Fig. 37 ref. 6**) turn green.

Fit weight on the position where pliers touches the wheel

Fig. 39



At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin. The ECO-WEIGHT procedure has now been completed.



IMMEDIATELY AFTER HAVING SELECTED THE ECO-WEIGHT PROCEDURE, YOU CAN KNOW IN ADVANCE THE TWO DYNAMIC UNBALANCES AND THE STATIC RESIDUE IN ORDER TO DECIDE WHETHER IT IS CONVENIENT TO CONTINUE (SEE FIG. 37).

IF BOTH DYNAMIC UNBALANCES AND STATIC RESIDUE ARE SHOWN AS WHITE VALUES ON THE MONITOR, THIS MEANS THAT THE PROGRAM HAS DECIDED THAT IT IS BETTER TO CONTINUE. WHILE IF, ON THE OTHER HAND, ONE OR MORE VALUES ARE BLUE, THE PROGRAM SUGGESTS USING THE STANDARD ALU-S PROCEDURE.



PRESS BUTTON . THE TWO RESIDUAL DYNAMIC UNBALANCES WILL BE DISPLAYED ON MONITOR.

PRESS THE BUTTON ONCE TO DISPLAY FIG. 37.

PLACE THE WEIGHT WHERE REQUIRED AND AND SPIN AGAIN.

13.8.2 SPLIT mode

Split procedure proves useful when the dynamic unbalance of a wheel is fairly high and the weight to be fitted is not available, for instance a 100 g weight. It's possible then to correct the unbalance dividing the amount of weight into two weights of smaller size.

Split procedure eliminates errors by using "DYNAMIC" program, for example by manually fitting two 50 g weights close to one another, instead of only a 100 gr one.

For example:

100 g WEIGHT
TO BE FITTED TO CORRECT UNBAL-
ANCE



TWO SMALLER WEIGHTS (50g)
FITTED MANUALLY




TWO SMALLER WEIGHTS (55g)
USING SPLIT PROCEDURE




Proceed to "DYNAMIC" unbalance measurement displaying by performing a standard wheel spin.



Once detected the unbalance values, verify that the machine displays the ability to use the "SPLIT" option



(Fig. 34 ref. 4a). Press button  to shift to the next screen page.



Press button  to enter "SPLIT" function. On the monitor screen will be displayed where you must enter the value of the weights to be fitted.



Press button  to select the outer weight to edit.

Press buttons  or  to increase or decrease the total weight to be fitted.



THE BLUE VALUE INDICATES WHICH VALUE IS ACTIVE AND YOU ARE EDITING.



THE HIGHER THE CHOSEN WEIGHTS VALUE IS, THE MORE THEY WILL BE SPACED.


After choosing the value of the weights to be fitted,

press button  to position the wheel for the application of the 1st clip weight.




THE TWO GREEN ARROWS INDICATE THAT THE WHEEL IS PROPERLY POSITIONED FOR THE APPLICATION OF THE 1ST WEIGHT.

Fit the clip weight of the chosen value at 12 o'clock on

the outside of the wheel. Press again button  to position the wheel for the fitting of the 2nd clip weight.



Fit the clip weight of the chosen value at 12 o'clock

on the outside of the wheel. Press button  to highlight the value of the weights to be fitted on the inside of the wheel.



Repeat the above steps for the weights to be fitted inside the wheel.

At the end perform again a checking spin to see that you have applied the weights correctly.


13.8.3 Weights hidden behind spokes mode

Adhesive correction weight positioning may not look attractive on some types of rims. In this case, the "weights hidden behind spokes" mode can be used. This splits any correction weight on the outer side into two parts to be hidden behind the rim spokes. It can be used in both ALU-S or STATIC modes.


Display the ALU-S or STATIC, unbalance measurements, by performing a standard wheel spin.



Once detected the unbalance values, verify that the machine displays the ability to use the "spokes" options (Fig. 34 ref. 4b).

Press button  to shift to the next screen page.



Press button  to enter the relevant function. On the monitor the next screen page will be displayed:



Bring any spoke upwards at "12 o'clock" position and



press the button to confirm and continue.



Lead to "12 hours" the 2nd spoke. The machine will automatically calculate the total number of spokes. If the value shown on the screen (A) is correct, press the



button

The machine automatically calculates weight position in two positions hidden behind the spokes. The monitor shows the amount of weight to be applied behind the FIRST spoke and the rim will reach the position to apply the FIRST weight.



Extract the gauge rod, and fit the FIRST weight in the position shown by the machine, as explained in



Par. 13.5.1. Press the button to confirm that they have applied the FIRST weight and to automatically position the wheel for the fitting of the 2nd weight. The monitor shows the amount of weight to be applied behind the SECOND spoke.

Pull out the gauge rod and fit the SECOND weight in the position shown by the machine, as done for the first weight.



Press the button to confirm that you have applied the SECOND weight and get back to the initial situation of unbalance, before performing the "weights hidden behind the spokes" procedure. Perform another test spin. The "weights hidden behind spokes" procedure is completed.

Complete the operation by adding an additional weight inside the rim as required by the selected mode (ALU-S or STATIC).

13.8.4 Matching mode

The "MATCHING" procedure offsets strong unbalance, reducing the weight quantity to be fitted on the wheel to achieve balancing. This procedure permits reducing unbalance as much as possible by offsetting the tyre unbalance with that of the rim in any used program.

Proceed to unbalance measurement displaying by performing a standard wheel spin.



THE MATCHING PROCEDURE CAN BE CARRIED OUT ONLY IF THE STATIC UNBALANCE IS > 30 G.



Once detected the unbalance values, verify that the machine displays the ability to use the "matching" options (**Fig. 34 ref. 4a**).



Press button to shift to the next screen page.




Press button to enter the relevant function. On the monitor the next screen page will be displayed:



STEP 1. Move the slider on the flange to the "12 o'clock" position. Make a reference mark, using chalk for instance, on the rim and tyre, in line with the arrow on the flange, so as to be able to fit the rim back on in the same position on the machine.

Make a reference mark on the rim and tyre, in line with the arrow on the flange




Press button  to confirm that step 1 has been completed.

On the display the next screen page will be displayed:




STEP 2. Remove the wheel from the wheel balancer. Remove the tyre and turn it on the rim through 180°.



Fit the wheel back on the wheel balancer, positioning the reference mark on the rim in line with the arrow on the flange.

Position the reference mark on the rim in line with the arrow on the flange



Position the tyre reference mark on the opposite side to the arrow on the flange



Press button  to confirm that step 2 has been completed.

On the display the next screen page will be displayed suggesting to perform a spin of the wheel.



After having fitted wheel back in position, close the protection guard to make an automatic wheel spin. At the end of the spin the monitor will display the following screen:

Fig. 40



In this screen you will see the dynamic unbalance that the wheel had before performing the operation (**Fig. 40 ref. 1**), the dynamic unbalance after having rotated the tyre of 180 ° compared to the rim (**Fig. 40 ref. 2**) and the unbalance which can be obtained following the directions of the machine (**Fig. 40 ref. 3**).

STEP 3. If the value of possible unbalance reduction is high, you can proceed as follows:

- Cancel the previously made reference marks. Put new signs, as described below.



- Press the button to bring the wheel into position.



Make the reference mark on RIM at 12 o' clock (see **Fig. 41**).

reference mark on
RIM



Fig. 41



- Press the button to bring the wheel into position.



Mark the reference mark on the TIRE at "12 o'clock" position.




- Press button to confirm that step 3 has been completed.

STEP 4. Remove the wheel from the wheel balancer. Dismount and remount the tyre on the rim so as to bring the two reference marks (rim and tyre) to coincide. Refit the wheel on the balancer (see **Fig. 42**) with the two reference marks next to the arrow on the flange.

Reference mark on
TYRE and reference
mark on RIM shall
coincide

Fig. 42



- Press button to confirm that step 4 has been completed.

Perform another spin closing the protection guard, to check the expected unbalance reduction and correct any residual unbalance, as described in Chap. 13.5.1.


13.9 Special balancing programs


13.9.1 Pax

The PAX mode is a special procedure specially devised to balance wheels using the "PAX System ®". 2 adhesive weights on different planes are used on rim inner side.

To launch a PAX measurement, proceed as follows:


- Make sure there are no stones and/or mud on the wheel. Remove any counterweights. Fit the wheel and make sure it is properly fastened (see Chapt. 11).

- Press  button from "Home" page. On the screen

that appears, press the button  to switch to measuring mode selection screen below.



Use the arrows  or  to select the PAX

mode. At the end press push button . The machine will be configured as follows to perform the measurement and on the video screen will appear the indication of the specific measures of the selected wheel type.

- Close the protection guard to perform the automatic wheel spin.

In just a few seconds, the wheel runs at normal speed and the monitor shows wheel rotation.

After the spin, the wheel stops automatically, taking into account the measured unbalance so that the fitting position of the weight will be at 12 o' clock.


The monitor show the weight required to correct the unbalance.


Open the protection guard and proceed to fit the adhesive weight as shown for the ALU-S mode (see Par. 13.7.5).


13.10 Recalculation function

After making a spin, the wheel automatically stops, indicating the weight/s to be fitted and its/their position. In case the operator does not want the type of wheel balance proposed by the machine (program type, weights size, etc ...), proceed with the re-calculation of the wheel balancing without rerunning the spin of the wheel.

To do this, proceed as described below:

- press key  to select a new balancing program though the arrows;

- take with the gauge arm the measures required by the selected program (if key  is missing);

- press button  to perform the re-calculation. The monitor will display the weights and the positions in which they will be applied.




If also in this case the operator should decide to further modify the balancing program, it is sufficient to proceed as described above without having to spin the wheel.

When the result of the recalculation does not satisfy the operator, it is recommended to do a spin of the wheel to confirm the findings from the operation of recalculation itself.

After the launch of the wheel, the machine, in addition to displaying the unbalance value, draw up automatically all the programs measurement fields that are consistent with those measures that were taken previously and at the same time erases all measures which are not consistent.


13.11 Motorbike mode wheel balancing

By enabling "motorbike wheel balancing" function, the wheel balancers can also balance motorbike wheels. Before detecting the wheel sizes (see Par. 13.2.2), select motorcycle wheel balancing mode proceeding as described below:

press button  and then button . On the screen that appears, press the button  to switch to programs and measurements acquisition selection screen below.



Use the arrows  or  to select the wished

mode. At the end press push button . The machine will be configured as follows to perform the measurement in the desired mode and on the screen will appear an indication showing the measures that will be acquired.

The "motorcycle" mode automatically recalculates the wheel distance measurement, increasing this by the length of the optional extension GAR181 A1.

To fit the extension (**Fig. 43 ref. 2**), first press the threaded ring nut (**Fig. 43 ref. 1**) in the hole provided and then screw the plastic terminal (see **Fig. 43**).



THE EXTENSION WILL ONLY HAVE TO BE SCREWED UP WHEN BALANCING IS PERFORMED IN "MOTORBIKE" MODE.





Fig. 43

Balancing procedures are identical for both modes (car/motorbike).


By selecting motorbike mode, besides DYNAMIC balancing (see Par. 13.7.4) STATIC balancing and/or ALU-S (Par. 13.7.1 and/or 13.7.5) can also be performed.

14.0 USER MENU (OPTIONS AND CALIBRATION)


From the main page "Home" press the button  to move to the next screen page and the button  to access the user menu. On the monitor, the following screen appears where you can enter the password.





The user login password is: **1234**. After entering the correct password you will see the following screen:





14.1 Options menu


Press button  to display the monitor screen to enable/disable the options as shown below:




To enable / disable individual functions simply highlight the icon using the buttons  and/or .

and press the button .


Pressing the button  may involve, besides, the change in the unit of measure from "mm" to "inch" and vice versa (where applicable) or access to a sub-screen for values settings values (see Par. 14.1.1 or 14.1.2). After you select/deselect the desired options, exit the

menu by pressing push-button . These options will be automatically stored.


List of available options




Enable/disable the protection guard/spin (enabled on machine delivery).




Enable/disable the distance/diameter detection caliper (enabled on machine delivery).




Enable/disable the display of static threshold after each spin (enabled on machine delivery).




It allows you to set the thresholds for each of the balancing mode weights (see Par. 14.1.1).



Enable/disable the lock function for caliper arm in position (disabled on machine delivery).




It allows you to change the unit of measurement of the weights from grams to ounces and vice versa.




It allows you to enable/disable the width function detected by GAR264 or GAR266 (enabled when fitted as standard on the machine).




Enable/disable the ECO-WEIGHT function (enabled on machine delivery).




Enable/disable the positioning of weights at "6 o'clock" (disabled on machine delivery).




Enable/disable the pneumatic brake after the spin (disabled on machine delivery).




It allows you to change the unit of measure of the distance of the weights fitting point from mm to inches and vice versa.




Enable/disable the led light (enabled if mounted on the machine).




Enable/disable the dynamic residues in the ECO-WEIGHT function (enabled on machine delivery).




Enable/disable the functions of motor-bike balancing (disabled on machine delivery).




Enable/disable the encoder mounted on the spin motor (disabled on machine delivery).




It allows you to change the unit of measurement of the rims width from mm to inches and vice versa.




It allows you to set the size values of weights (see Par. 14.1.2).



Enable/disable the RUN-OUT functions (enabled on machine delivery).




Enable/disable machine print functions (disabled on machine delivery).




It allows the setting of the retrieval of the measures by eye: readout of measures printed on the rim and the graduated scale of the distance-diameter caliper (disabled on machine delivery).

NOTE: it is activated only if distance-diameter caliper is disabled.




Enable/disable the use of the manual caliper to measure rim width (disabled on machine delivery).


NOTE: it is activated only if distance-diameter caliper is disabled.




It allows you to change the unit of measurement of the rim diameter from mm to inches and vice versa.



Enable/disable the functions of weights positioning laser (GAR311) (disabled on machine delivery).



Enable/disable the repositioning of the wheel at the end of the spin (enabled on machine delivery).



Enable/disable user function (disabled on machine delivery).

14.1.1 Lower weight limit

Correction weight below a certain limit is normally shown equal to zero. This limit can be set from 10 g to 1 g.

At the end of the spin however, by pressing the button



, the weight can be displayed with max resolution of 1 g, not considering the set lower limit.



IN THE PLANT, THE LOWER LIMIT FOR THE DYNAMIC WHEEL BALANCING MODE IS SET TO 5 g. THE LOWER LIMIT FOR ALL THE OTHER MODES IS SET TO 7 g.





KEY

- 1 – Lower weight limit in the DYNAMIC program to display "OK" (default value 5 g)
- 2 – Lower weight limit in the ALU-STATIC program to display "OK" (default value 7 g)
- 3 – Weights display resolution (default value 5 g)
- 4 – Weight % reduction in ECO-WEIGHT function (0 ÷ 200) (default value 100)

14.1.2 Setting adhesive weight dimensions and static threshold percentage

To ensure the balancing machine precisely calculates the dimensions and total adhesive weights, set the height (thickness) and width of the adhesive weights at your disposal (see **Fig. 45**).

Fig. 45





To carry out this setting, press the icon . You will see the following screen:



KEY

- 1 – Weights thickness (height) (default value 4 mm)
- 2 – Weights width (default value 19 mm)

From this screen page, change the size values of weights


using buttons  and .




THE BLUE-COLOURED-VALUE IS THE ACTIVE FIELD AND THE MODIFIABLE ONE.

14.1.3 User management

The "User Management" function is disabled on machine delivery. To enable it, proceed as described in Para 14.1. After enabling, the icon will be displayed on every page (**Fig. 46 ref. 1**).
The wheel balancers can be used simultaneously by 4 different users.





Press button , shown on the monitor (**Fig. 46 ref. 2**) or select the field (**Fig. 47 ref. 1**) and subsequently press the button  to display the screen below:



KEY
A – Program used in the last carried out spin
B – Acquired measurements for the last carried out spin


Press any of the available numbers on the buttons at the bottom of the page to select the corresponding user. The system stores the data relating to the last performed spin according to the different operators. You can recall the desired user each time the program displays the specific button (**Fig. 46 ref. 2** and **Fig. 47 ref. 1**). The measurements stored for each user are lost when the machine is switched off. User management is valid for any wheel balancer function.



TO ENABLE OR DISABLE "USER MANAGEMENT" FUNCTION, SEE PARAGRAPH 14.1. IF THE FUNCTION IS DEACTIVATED, THE BUTTON  IS DISPLAYED.

14.2 Machine calibration


Press the button  (Fig. 44 ref. 2) to display the following screen page on monitor:



KEY

- 1 – Mandrel zero calibration
- 2 – Weight measurement sensors calibration
- 3 – Gauge calibration

14.2.1 Mandrel “Ø” calibration


Press the button  to display the following screen page on the monitor:



After making sure that the spindle is unloaded (no wheel or mounted accessories), press the button




and close the guard. The spindle will rotate for about 30 seconds until you see the screen below:



At this point the machine has all its measuring fields.




Press button  to return to calibrations screen page.

14.2.2 Weight measurement sensors calibration



ASSEMBLE A BALANCED WHEEL ON THE SPINDLE AND PERFORM THE SPINDLE “ZERO” CALIBRATION PROCEDURE DESCRIBED IN PAR. 14.2.1 (WITH WHEEL MOUNTED).





- Press on the button  to display the following screen page:



- Set the size of the rim on the mandrel using the distance-diameter caliper arm and the external data gauge (if present) or manual caliper.



- Press the button  and close the guard to the perform the 1st spin of the wheel without weights.
- At the end, on the monitor will appear the following screen, saying that you should apply a weight of 100 g to the "12 o'clock" outer rim.



APPLY THE WEIGHT AT A POINT IN WHICH BOTH SIDES OF THE RIM THERE IS THE POSSIBILITY OF APPLYING A CLIP WEIGHT OF 100 g.

- Apply the weight and position it perfectly to the "12 o'clock".




- Press the button and close the guard to perform the 2nd spin of the wheel (100 g weight placed on the outside of the wheel).
- At the end the following screen will appear on the monitor, suggesting to remove the weight of 100 g previously applied on the outer side and apply it on the inside of the rim.



- Turn manually the wheel until you have the weight of 100 g on the outer side at "12 o'clock".
- Press the brake pedal and hold it down during the whole the following operation to avoid unexpected rotation of the spindle.
- Remove the weight from 100 g from the outside of the wheel and apply it on the inner side at "12 o'clock".
- Close the guard to perform the 3rd spin of the wheel (100 g weight placed on the inside wheel).

At the end of the rotation, the video screen below will be displayed to indicate that the operation is finished.



WHEN THE OPERATION IS CONCLUDED, REMOVE THE WHEEL FROM THE MANDREL AND PERFORM A COMPLETE CALIBRATION PROCEDURE ZERO MANDREL AS DESCRIBED IN PAR. 14.2.1.

14.2.3 Gauge calibration



Press the button to display the following screen page on the monitor:



1 2

KEY

- 1 – Distance-diameter caliper calibration
- 2 – External data gauge calibration


Distance-diameter caliper calibration




Press the button to display the following screen page on the monitor:



Place the gauge (**Fig. 48 ref. 1**) on the mandrel flange (**Fig. 48 ref. 2**).




The following screen will appear on the monitor to indicate the measured values:



- The value next to the symbol "scale" (**Fig. 49 ref. 1**) must be equal to the value positioned above the gauge (**Fig. 49 ref. 2**) ± 1 mm.


- Press push button .


The following screen will appear on the monitor:



- Place the gauge as shown in the following figure:



- Press push button . Wait a few seconds until you see the following screen:



- Place the gauge against the mandrel in the lower part of it but on a smaller diameter than before as indicated on the image on the monitor.

- Press push button .

On the monitor the next screen page will be displayed:



Measure the exact diameter of a rim (see **Fig. 50**) and place it on the screen on the monitor by pressing the



or





buttons.


Fig. 50

- Fit the measured wheel on the balancer and lock it on the mandrel.
- Turn the gauge ferrule (**Fig. 51 ref. 1**) on the inner edge of the wheel upwards (see **Fig. 51**).


Fig. 51


- Press button  to end the operation. On the monitor the next screen page will be displayed:




Distance-diameter caliper calibration is finished.

Calibration of external data gauge (optional)




Press the button  to display the following screen page on the monitor:




**TO PERFORM THIS CALIBRATION,
THE MANDREL MUST BE UNLOAD-
ED (NO WHEEL OR ACCESSORIES
MOUNTED ON IT).**

Move the tip of the width measuring device (**Fig. 52-53 ref. 1**) in line with the mandrel edge (**Fig. 52-53 ref. 2**).



Fig. 52


GAR264


Fig. 53


GAR266





Press button .
On the monitor the next screen page will be displayed:



Move the tip of the width measuring device (**Fig. 54 ref. 1**) in line with the outer surface of the flange (**Fig. 54 ref. 2**).



Press button . At the end of the operation, the following screen will appear on the monitor:



The calibration of the external data gauge is finished.


15.0 ERROR SIGNALS

During wheel balancer operation, if wrong commands are given by the operator or device faults occur, an error code may appear on the monitor screen.


Below is a troubleshooting chart.

Error code	Description
2	Planned wheel speed not reached
3	Calibration overcoming
4	Wheel speed stability out of tolerance
5	Encoder calibration error
6	Encoder samples not sufficient
7	Mandrel calibration error
8	Piezo calibration values out of tolerance
9	Wheel rotations not completed
11	Incorrect gain calibration
12	Distance-diameter caliper value not released
13	Distance-diameter caliper value not released
14	Firmware error
15	Runout samples not sufficient
17	External data gauge enabled
27	Rotate the wheel to make a complete rotation
28	Piezo calibration error
29	Distance out of tolerance level
31	Distance-diameter caliper released
32	Parameters format incompatible

16.0 ROUTINE MAINTENANCE



BEFORE CARRYING OUT ANY ROUTINE MAINTENANCE OR ADJUSTMENT PROCEDURE, POSITION THE MAIN SWITCH “0”, DISCONNECT THE MACHINE FROM THE ELECTRICITY SUPPLY USING THE SOCKET/PLUG COMBINATION AND CHECK THAT ALL MOBILE PARTS ARE AT A STANDSTILL.




BEFORE EXECUTING ANY MAINTENANCE OPERATION, MAKE SURE THERE ARE NO WHEELS LOCKED ONTO THE MANDREL.

To guarantee the efficiency and correct functioning of the machine, it is essential to carry out daily or weekly cleaning and weekly routine maintenance, as described below.

Cleaning and routine maintenance must be conducted by authorized personnel and according to the instructions given below.

- Remove deposits of tyre powder and other waste materials with a vacuum cleaner.
- DO NOT BLOW IT WITH COMPRESSED AIR.**
- Do not use solvents to clean the pressure regulator.




ANY DAMAGE TO THE MACHINE DEVICES RESULTING FROM THE USE OF LUBRICANTS OTHER THAN THOSE RECOMMENDED IN THIS MANUAL WILL RELEASE THE MANUFACTURER FROM ANY LIABILITY!!

17.0 TECHNICAL DATA

	ATLASWB80
Wheel max. weight (Kg)	70
Max. absorbed voltage (W)	200
Power supply	110 - 230V 50/60 Hz 1 ph
Balancing precision (g)	± 1
Balancing speed (rpm)	< 100
Rim width setting (inches)	$1.5'' \div 22''$
Rim diameter setting (inches)	$10'' \div 26''$ (manually up to 30'')
Max wheel diameter inside protection (inches)	40''
Max wheel width inside protection (mm)	560
Sound emission level (dBA)	< 70
Cycle time (sec)	6
Weight (Kg)	90

17.1 Dimensions

Fig. 55



18.0 STORING

If storing for long periods disconnect the main power supply and take measures to protect the machine from dust build-up. Lubricate parts that could be damaged from drying out.


19.0 SCRAPPING

When the decision is taken not to make further use of the machine, it is advisable to make it inoperative by removing the connection pressure hoses. The machine is to be considered as special waste and should be dismantled into homogeneous parts. Dispose of it in accordance with current legislation.

Instructions for the correct management of waste from electric and electronic equipment (WEEE) according to the Italian legislative decree 49/14 and subsequent amendments.

In order to inform the users on the correct way to dispose the product (as required by the article 26, paragraph 1 of the Italian legislative decree 49/14 and subsequent amendments), we communicate what follows: the meaning of the crossed dustbin symbol reported on the equipment indicates that the product must not be thrown among the undifferentiated rubbish (that is to say together with the "mixed urban waste"), but it has to be managed separately, to let the WEEE go through special operations for their reuse or treatment, in order to remove and dispose safely the waste that could be dangerous for the environment and to extract and recycle the raw materials to be reused.

Fig. 56



20.0 REGISTRATION PLATE DATA

		SPACE s.r.l. 10090 TRANA (TO) Via Sangano 48 Tel 011-93440300 Fax 011-9338864
MODEL		
SERIAL N°	YEAR	

The validity of the Conformity Declaration enclosed to this manual is also extended to products and/or devices the machine model object of the Conformity Declaration can be equipped with.




ATTENTION: TAMPERING WITH, CARVING, CHANGING ANYHOW OR EVEN REMOVING MACHINE IDENTIFICATION PLATE IS ABSOLUTELY FORBIDDEN; DO NOT COVER IT WITH TEMPORARY PANELS, ETC., SINCE IT MUST ALWAYS BE VISIBLE.

Said plate must always be kept clean from grease residues or filth generally.

WARNING: Should the plate be accidentally damaged (removed from the machine, damaged or even partially illegible) inform immediately the manufacturer.

21.0 FUNCTIONAL DIAGRAMS

Here follows a list of the machine functional diagrams.



ATLASWB80

WIRING CONNECTION DIAGRAM

1296-M015-0

Table N°A - Rev. 0

Page 55 of 56

GB

KEY

- 1 – Monitor 19"
- 2 – Monitor card kit
- 3 – Monitor card kit
- 4 – Transformer
- 5 – Tilting switch
- 6 – DC motor
- 7 – Cable for pedal micro
- 8 – Push-button panel with 7 keys
- 9 – Led light
- 10 – Motor support ground cable
- 11 – Runout keyboard extension cable
- 12 – Cable from switch to transformer
- 13 – Fuse
- 14 – Keyboard cables
- 15 – Front piezo cables
- 16 – Rear piezo cables
- 17 – Phonic wheel encoder cables
- 18 – Distance-diameter caliper cables
- 19 – Cable for wheel micro protection
- 20 – Power supply cable
- 21 – Potentiometer with cable
- 22 – Cable for solenoid valve EVC
- 23 – Cable for solenoid valve EVO
- 24 – Potentiometer extension cable
- 25 – Ultrasound sensors extension cable

ATLASWB80			
	WIRING CONNECTION DIAGRAM		1296-M015-0
			Page 56 of 56
	Table N°A - Rev. 0		GB

1296-R015-0

ATLASWB80

- I** 22.0 LISTA DEI COMPONENTI
- GB** 22.0 LIST OF COMPONENTS
- D** 22.0 TEILELISTE
- F** 22.0 LISTE DES PIECES DETACHEES
- E** 22.0 LISTA DE PIEZAS



GLI ESPLOSI SERVONO SOLO PER L'IDENTIFICAZIONE DELLE PARTI DA SOSTITUIRE. LA SOSTITUZIONE DEVE ESSERE EFFETTUATA DA PERSONALE PROFESSIONALMENTE QUALIFICATO.



THE DIAGRAMS SERVE ONLY FOR THE IDENTIFICATION OF PARTS TO BE REPLACED. THE REPLACEMENT MUST BE CARRIED OUT PROFESSIONALLY QUALIFIED PERSONNEL.



DIE ZEICHNUNGEN DIENEN NUR ZUR IDENTIFIZIERUNG DER ERSATZTEILE. DIE ERSETZUNG MUSS DURCH QUALIFIZIERTES PERSONAL ERFOLGEN.



LES DESSINS NE SERVENT QU'À L'IDENTIFICATION DES PIÈCES À REMPLACER. LE REMPLACEMENT DOIT ÊTRE EFFECTUÉ PAR UN PERSONNE PROFESSIONNELLEMENT QUALIFIÉ.



LOS DIBUJOS EN DESPIECE SIRVEN ÚNICAMENTE PARA IDENTIFICAR LAS PIEZAS QUE DEBEN SUSTITUIRSE. LA SUSTITUCIÓN DE PIEZAS DEBE EFECTUARLA EXCLUSIVAMENTE PERSONAL PROFESIONALMENTE CUALIFICADO.

- Per eventuali chiarimenti interpellare il più vicino rivenditore oppure rivolgersi direttamente a:
- For any further information please contact your local dealer or call:
- Im Zweifelsfall oder bei Rückfragen wenden Sie sich bitte an den nächsten Wiederverkäufer oder direkt an:
- Pour tout renseignement complémentaire s'adresser au revendeur le Plus proche ou directement à:
- En caso de dudas, para eventuales aclaraciones, póngase en contacto con el distribuidor más próximo ó diríjase directamente a:

Technical services: **SPACE s.r.l. a s.u.** - Via Sangano, 48 - 10090 Trana - Torino Italy
Phone (+39) 011 93440300 - Fax (+39) 011 9338864 - e-mail: spacesrl@tin.it

	LISTA DEI COMPONENTI LIST OF COMPONENTS TEILELISTE LISTE DES PIÈCES DÉTACHÉES LISTA DE PIEZAS	Pag. 2 di 19
		ATLASWB80

1296-R015-0

SOMMARIO - SUMMARY - INHALT

SOMMAIRE - SUMARIO

Tavola N°1 - Rev. 0 ____ 3

ASSIEME GENERALE
MAIN ASSEMBLY
GENERALSATZ
ASSEMBLAGE GENERAL
JUNTO GENERAL

Tavola N°2 - Rev. 0 ____ 129690073 5

GRUPPO MOTORE
MOTOR UNIT
MOTORSATZ
GROUPE MOTEUR
GRUPO MOTOR

Tavola N°3 - Rev. 0 ____ 129690090 6

GRUPPO ROTANTE COMPLETO
COMPLETE ROTARY UNIT
KOMPLETTER ROTIERENDER SATZ
GROUPE ROTATIF COMPLET
GRUPO GIRATORIO COMPLETO

Tavola N°4 - Rev. 0 ____ 129690292 7

GRUPPO FRENO
BRAKE UNIT
BREMSATZ
GROUPE FREIN
GRUPO FRENO

Tavola N°5 - Rev. 0 ____ 129695834 8

GRUPPO TELAIO
FRAME UNIT
RAHMENSATZ
GROUPE CHASSIS
GRUPO ESTRUCTURA

Tavola N°6 - Rev. 0 ____ 129695851 9

GRUPPO PLANCIA
BOARD UNIT
BRETTSATZ
GROUPE PLANCHE
GRUPO TABLERO

Tavola N°7 - Rev. 0 ____ 129690331 10

GRUPPO CALIBRO
TESTER UNIT
KALIBERSATZ
GROUPE CALIBRE
GRUPO CALIBRE

Tavola N°8 - Rev. 0 ____ 129690152 11

GRUPPO AZIONAMENTO FRENO
BRAKE OPERATION GROUP
SATZ FÜR BREMSBETÄTIGUNG
GROUPE ACTIONNEMENT FREIN
GRUPO ACCIONAMIENTO FRENO

Tavola N°9 - Rev. 0 ____ 129690611 12

GRUPPO PEDALE FRENO
BRAKE PEDAL UNIT
BREMSE PEDALSATZ
GROUPE PÉDAL FREIN
GRUPO PEDAL FRENO

Tavola N°10 - Rev. 0 ____ 129793090 13

GRUPPO ELETTRONICA
ELECTRONICS UNIT
ELEKTRONIKSATZ
GROUPE ÉLECTRONIQUE
GRUPO ELECTRÓNICA

Tavola N°11 - Rev. 0 ____ 129690341 14

GRUPPO IMPIANTO ELETTRICO
ELECTRICAL SYSTEM UNIT
SATZ VON ELEKTROANLAGE
GROUPE INSTALLATION ÉLECTRIQUE
GRUPO INSTALACIÓN ELÉCTRICA

Tavola N°12 - Rev. 0 ____ 129390201 15

GRUPPO PROTEZIONE RUOTA
WHEEL PROTECTION UNIT
SATZ FÜR RADSCHUTZ
GROUPE PROTECTION ROUE
GRUPO PROTECCIÓN RUEDA

Tavola N°13 - Rev. 0 ____ 16

DOTAZIONE C
C EQUIPMENT
AUSSTATTUNG C
DOTATION C
DOTACION C

Tavola N°14 - Rev. 0 ____ GAR266 17


CALIBRO LARGHEZZA
WIDTH CALIPER
KALIBER FÜR BREITE
CALIBRE LARGEUR
CALIBRE ANCHO

Tavola N°15 - Rev. 0 ____ 129794160 18

GRUPPO LASER FISSO + ILLUMINATORE
FIXED LASER + LIGHTING DEVICE UNIT
FESTLASER + BELEUCHTUNG SATZ
GROUPE LASER FIXE + DISPOSITIF D'ÉCLAIRAGE
GRUPO LASER FIJO + ILUMINADOR

Tavola N°16 - Rev. 0 ____ GAR264 19

CALIBRO LARGHEZZA PROFESSIONALE
PROFESSIONAL EXTERNAL DATA GAUGE
BERUFLICHE BREITENLEHRE
CALIBRE LARGEUR PROFESSIONNEL
CALIBRE ANCHO PROFESIONAL



LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE
LISTE DES PIÉCES DÉTACHÉES - LISTA DE PIEZAS

Tavola N°1 - Rev. 0

ASSIEME GENERALE
MAIN ASSEMBLY
GENERALSATZ
ASSEMBLAGE GENERAL
JUNTO GENERAL


Pag. 3 di 19

ATLASWB80


1296-R015-0

[illegible]


OPT = OPTIONAL




ATLASWB80			
•			
LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS		GRUPPO MOTORE MOTOR UNIT MOTORSATZ GROUPE MOTEUR GRUPO MOTOR	
Tavola N°2 - Rev. 0	129690073	Pag. 5 di 19	




ATLASWB80			
•			
	LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS		GRUPPO ROTANTE COMPLETO COMPLETE ROTARY UNIT KOMPLETTER ROTIERENDER SATZ GROUPE ROTATIF COMPLET GRUPO GIRATORIO COMPLETO
	Tavola N°3 - Rev. 0	129690090	




ATLASWB80			
•			
	LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS		GRUPPO FRENO BRAKE UNIT BREMSATZ GROUPE FREIN GRUPO FRENO
	Tavola N°4 - Rev. 0	129690292	




ATLASWB80			
•			
	LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS		GRUPPO TELAIO FRAME UNIT RAHMENSATZ GROUPE CHASSIS GRUPO ESTRUCTURA
	Tavola N°5 - Rev. 0	129695834	




ATLASWB80			
	LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS		GRUPPO PLANCIA BOARD UNIT BRETTSATZ GROUPE PLANCHE GRUPO TABLERO
	Tavola N°6 - Rev. 0	129695851	




ATLASWB80			
•			
	LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS		GRUPPO CALIBRO TESTER UNIT KALIBERSATZ GROUPE CALIBRE GRUPO CALIBRE
	Tavola N°7 - Rev. 0	129690331	




ATLASWB80				
•				
	LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE LISTE DES PIECES DETACHEES - LISTA DE PIEZAS		GRUPPO AZIONAMENTO FRENO BRAKE OPERATION GROUP SATZ FÜR BREMSBETÄTIGUNG GROUPE ACTIONNEMENT FREIN GRUPO ACCIONAMIENTO FRENO	Pag. 11 di 19
	Tavola N°8 - Rev. 0	129690152		




ATLASWB80			
•			
LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS		GRUPPO PEDALE FRENO BRAKE PEDAL UNIT BREMSE PEDALSATZ GROUPE PÉDAL FREIN GRUPO PEDAL FRENO	Pag. 12 di 19
Tavola N°9 - Rev. 0		129690611	




ATLASWB80			
•			
LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE LISTE DES PIÉCES DÉTACHÉES - LISTA DE PIEZAS		GRUPPO ELETTRONICA ELECTRONICS UNIT ELEKTRONIKSATZ GROUPE ÉLECTRONIQUE GRUPO ELECTRÓNICA	Pag. 13 di 19
Tavola N°10 - Rev. 0		129793090	




ATLASWB80			
•			
	LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS		GRUPPO IMPIANTO ELETTRICO ELECTRICAL SYSTEM UNIT SATZ VON ELEKTROANLAGE GROUPE INSTALLATION ÉLECTRIQUE GRUPO INSTALACIÓN ELÉCTRICA
	Tavola N°11 - Rev. 0	129690341	




ATLASWB80			
•			
	LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS		GRUPPO PROTEZIONE RUOTA WHEEL PROTECTION UNIT SATZ FÜR RADSCHUTZ GROUPE PROTECTION ROUE GRUPO PROTECCIÓN RUEDA
	Tavola N°12 - Rev. 0	129390201	



ATLASWB80				
●				
	LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE LISTE DES PIECES DETACHEES - LISTA DE PIEZAS		DOTAZIONE C C EQUIPMENT AUSSTATTUNG C DOTATION C DOTACION C	Pag. 16 di 19
	Tavola N°13 - Rev. 0			




ATLASWB80			
●			
	LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS		CALIBRO LARGHEZZA WIDTH CALIPER KALIBER FÜR BREITE CALIBRE LARGEUR CALIBRE ANCHO
	Tavola N°14 - Rev. 0	GAR266	



ATLASWB80			
•			
	LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE LISTE DES PIÉCES DÉTACHÉES - LISTA DE PIEZAS		Pag. 18 di 19
	Tavola N°15 - Rev. 0	129794160	

GRUPPO LASER FISSO + ILLUMINATORE
 FIXED LASER + LIGHTING DEVICE UNIT
 FESTLASER + BELEUCHTUNG SATZ
 GROUPE LASER FIXE + DISPOSITIF D'ÉCLAIRAGE
 GRUPO LASER FIJO + ILUMINADOR



ATLASWB80			
OPT			
	LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS		CALIBRO LARGHEZZA PROFESSIONALE PROFESSIONAL EXTERNAL DATA GAUGE BERUFLICHE BREITENLEHRE CALIBRE LARGEUR PROFESSIONNEL CALIBRE ANCHO PROFESIONAL
	Tavola N°16 - Rev. 0	GAR264	