


Adjusting the Lowering Speed of the EML-1200 Motorcycle Lift

The Power Unit of the EML-1200 has a Lowering Speed Control Valve. This is used to control the rate of descent. Below you can see The Lowering Speed Control Valve.



The Lowering Speed Control Valve is located directly behind the Hydraulic connection to the Power Unit. Turn Clockwise to slow the descent and Counter-Clockwise to accelerate the descent. Be sure to test the speed without weight and that you always secure anything placed on the lift according to manufacturer's specifications.

